Digital Home Entertainment System user manual

Imagine the possibilities

Thank you for purchasing this Samsung product.

To receive more complete service,
please register your product at

www.samsung.com/register



Safety Information

Safety Warnings

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER(OR BACK). NO USER-SERVICEABLE PARTS ARE INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This symbol indicates "dangerous voltage" inside the product that presents a risk of electric shock or personal injury.

CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.



This symbol indicates important instructions accompanying the product.

WARNING

• To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

CAUTION

- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- · The Mains plug is used as a disconnect device and shall stay readily operable at any time.
- · This apparatus shall always be connected to an AC outlet with a protective grounding connection.
- To disconnect the apparatus from the mains, the plug must be pulled out from the mains socket, therefore the mains plug shall be readily operable.

CLASS 1 LASER PRODUCT KLASSE 1 LASER PRODUKT **LUOKAN 1** LASER LAITE KLASS 1 LASER APPARAT PRODUCTO LÁSER CLASE 1

CLASS 1 LASER PRODUCT

This Compact Disc player is classified as a CLASS 1 LASER product.

Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION

 INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED. AVOID EXPOSURE TO BEAM.

Precautions

- Ensure that the AC power supply in your house complies with the identification sticker located on the back of your product.
- Install your product horizontally, on a suitable base (furniture), with enough space around it for ventilation (7.5~10cm).
- Do not place the product on amplifiers or other equipment which may become hot. Make sure the ventilation slots are not covered.
- . Do not stack anything on top of the product.
- · Before moving the product, ensure the Disc Insert Hole is empty.
- In order to disconnect the product completely from the power supply, remove the AC plug from the wall outlet, especially when left unused for a long period of time.
- · During thunderstorms, disconnect the AC plug from the wall outlet. Voltage peaks due to lightning could damage the product.
- Do not expose the product to direct sunlight or other heat sources. This could lead to overheating and malfunction of the
- Protect the product from moisture, and excess heat or equipment creating strong magnetic or electric fields (i.e. speakers.).
- Disconnect the power cable from the AC supply if the product malfunctions.
- Your product is not intended for industrial use. Use of this product is for personal use only.
- · Condensation may occur if your product or disc has been stored in cold temperatures. If transporting the product during the winter, wait approximately 2 hours until the product has reached room temperature before using.
- The batteries used with this product contain chemicals that are harmful to the environment. Do not dispose of batteries in the general household trash.

Accessories

Check for the supplied accessories below.



Safety Information

Cautions on Handling and Storing Discs

Small scratches on the disc may reduce sound and picture quality or cause skipping.

Be especially careful not to scratch discs when handling them.

Holding discs

- . Do not touch the playback side of the disc.
- Hold the disc by the edges so that fingerprints will not get on the surface.
- Do not stick paper or tape on the disc.



Disc Storage

- · Do not keep in direct sunlight
- · Keep in a cool ventilated area
- Keep in a clean Protection jacket.
 Store vertically.



- Do not allow the discs to become contaminated with dirt.
- Do not load cracked or scratched discs.

Handling and Storing Discs

If you get fingerprints or dirt on the disc, clean it with a mild detergent diluted in water and wipe with a soft cloth.

 When cleaning, wipe gently from the inside to the outside of the disc



Condensation may form if warm air comes into contact with cold parts inside the product. When condensation forms inside the product, it may not operate correctly. If this occurs, remove the disc and let the product stand for 1 or 2 hours with the power on.

Licence



 Dolby and the double-D symbol are registered trademarks of Dolby Laboratories.



- ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX,LLC, a subsidiary of Rovi Corporation. This is an official DivX Certified® device that plays DivX video. Visit divx.com for more information and software tools to convert your files into DivX videos.
- ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu. Go to vod.divx.com for more information on how to complete your registration.
- · DivX Certified® to play DivX® video.
- DivX®, DivX Certified® and associated logos are trademarks of Rovi Corporation or its subsidiaries and are used under license.
- Covered by one or more of the following U.S. patents: 7,295,673; 7,460,668; 7,515,710; 7,519,274.
- This product uses some software programs which are distributed under the Independent JPEG Group.
- This product uses some software programs which are distributed under the OpenSSL Project.

Copyright

© 2012 Samsung Electronics Co., Ltd. All rights reserved.

Copy Protection

 Many DVD discs are encoded with copy protection.
 Because of this, you should only connect your product directly to your TV, not to a VCR. Connecting to a VCR results in a distorted picture from copy-protected DVD discs.

Contents

SAFETY INFORMATION

- Safety Warnings 2 3 Precautions
- 3 Accessories
- 4 Cautions on Handling and Storing Discs
- Licence
- Copyright
- Copy Protection

GETTING STARTED

- Icons that will be used in manual
- 7 Disc Types and Characteristics
- 10 Description
- 10 Front Panel
- Rear Panel 11
- 12 Remote control

CONNECTIONS

- 13 Connecting the Speakers
- 15 Connecting the Video Out to your TV
- 16 Connecting the FM Antenna
- 17 Connecting Audio from External Components
- 17 Connecting Microphone

SETUP

- 18 Before Starting (Initial Settings)
- Setting the Setup menu 18
- 19 Display
- TV Aspect 19
- 19 Video Out Signal(option)
- 19 Audio
- 19 Speaker Setting 20
 - DRC (Dynamic Range Compression)
- 20 AUDIO SYNC
- 20 User EQ
- 20 Karaoke Scoring
- 20 System
- 20 Initial Settings
- 20 DivX(R) Registration
- 21 Language
- 21 Security
- 21 Parental Rating
- 21 Change Password
- 21 Support
- 21 Product Information

Contents

BASIC FUNCTIONS

- 21 Disc Playback
- 22 Audio CD(CD-DA)/MP3/WMA Playback
- 22 JPEG File Playback
- 23 Using the Playback Function
- 26 Sound Mode
- 28 Listening to Radio

ADVANCED FUNCTIONS

- 29 USB Function
- 29 USB Recording

OTHER INFORMATION

- 30 Troubleshooting
- 31 Language code list
- 32 Specifications
- 33 OpenSSL License
- Figures and illustrations in this User Manual are provided for reference only and may differ from actual product appearance.
- An administration fee may be charged if either
 - a. an engineer is called out at your request and there is no defect in the product (i.e. where you have failed to read this user manual)
 - b. you bring the unit to a repair centre and there is no defect in the product (i.e. where you have failed to read this user manual).
- The amount of such administration charge will be advised to you before any work or home visit is carried out.

Getting Started

Icons that will be used in manual

Make sure to check the following terms before reading the user manual.

Icon	Term	Definition
○ DVD	DVD	This involves a function available with DVD-Video or DVD±R/±RW discs that have been recorded and finalised in Video Mode.
(CD)	CD	This involves a function available with a data CD (CD DA, CD-R/-RW).
€ MP3	MP3	This involves a function available with CD-R/-RW discs.
JPEG	JPEG	This involves a function available with CD-R/-RW discs.
€ DivX	DivX	This involves a function available with MPEG4 discs. (DVD±R/±RW, CD-R/-RW)
!	CAUTION	This involves a case where a function does not operate or settings may be cancelled.
	NOTE	This involves tips or instructions on the page that help each function operate.
₹m	Shortcut Key	This function provides direct and easy access pressing the button on the remote control.

Disc Types and Characteristics

Region Code

The product and the discs are coded by region. These regional codes must match in order for the disc to play. If the codes do not match, the disc will not play.

Disc Type	Region Code	Area
		The U.S., U.S. territories and Canada
	2	Europe, Japan, the Middle East, Egypt, South Africa, Greenland
	3	Taiwan, Korea, the Philippines, Indonesia, Hong Kong
DVD-VIDEO		Mexico, South America, Central America, Australia, New Zealand, Pacific Islands, Caribbean
	(5)	Russia, Eastern Europe, India, most of Africa, North Korea, Mongolia
	6	China

Getting Started

Disc Types and Characteristics

Disc types that can be played

Disc Types & Mark (Logo)	Recorded Signals	Characteristics
		DVD video
VIDEO	VIDEO	DVD-R/DVD-RW IN DVD video FORMAT
DVD-VIDEO		DVD+R/DVD+RW IN DVD video FORMAT
DISITAL AUDIO AUDIO-CD	AUDIO	AUDIO CD
DIVX	AUDI0	AUDIO CD
DivX	+ VIDE0	CD-R/CD-RW in AUDIO CD FORMAT
	DATA CD	CD-R/CD-RW in DATA CD FORMAT that contains the following kinds of files and conforms to ISO 9660 LEVEL 1/LEVEL 2, OR JOLIET (EXTENDED FORMAT) -MP3 files -JPEG Image files -MPEG 4 VIDEO files
	DATA DVD	DVD-ROM/DVD-R/DVD-RW DVD+R/DVD+RW IN DATA DV FORMAT that contains the following kinds of files and conforms to UDF(*Universal Disk Format) -MP3 files -JPEG Image files -MPEG 4 VIDEO files
	USB Device	USB Device that contains the following kinds of files. -MP3 FILE OR WMA/WMV files -JPEG Image files -MPEG 4 Video files

Do not use the following type of discs!

- LD, CD-G, CD-I, CD-ROM, DVD-ROM and DVD-RAM discs cannot be played on this product. If such discs are played, a <WRONG DISC FORMAT> message appears on the TV screen.
- DVD discs purchased abroad may not play on this product.

If such discs are played, a <Wrong Region. Please check Disc.> message appears on the TV screen.

Disc Types And Disc Format

This product does not support Secure (DRM) Media files.

CD-R Discs

- Some CD-R discs may not be playable depending on the disc recording device (CD-Recorder or PC) and the condition of the disc.
- Use a 650MB/74 minute CD-R disc.
 Do not use CD-R discs over 700MB/80 minutes as they may not be played back.
- Some CD-RW (Rewritable) media, may not be playable.
- Only CD-Rs that are properly "closed" can be fully played. If the session is closed but the disc is left open, you may not be able to fully play the disc.

CD-R MP3 Discs

- MP3 file names should contain no blank spaces or special characters (. / = +).
- Use discs recorded with a compression/ decompression data rate greater than 128Kbps.
- If the disc is not closed, it will take longer to begin playback and not all of the recorded files may be played.
- For files encoded in Variable Bit Rate (VBR) format, i.e. files encoded in both low bit rate and high bit rate (e.g., 32Kbps ~ 320Kbps), the sound may skip during playback.
- A maximum of 500 tracks can be played per CD.
- A maximum of 300 folders can be played per CD.

CD-R JPEG Discs

- A maximum of 999 images can be stored on a folder.
- When playing a Kodak/Fuji Picture CD, only the JPEG files in the picture folder can be played.
- Picture discs other than Kodak/Fuji Picture CDs may take longer to start playing or may not play at all.

DVD±R/±RW, CD-R/RW Discs

- Software updates for incompatible formats are not supported.
 - (Example : QPEL, GMC, resolutions higher than 800 x 600 pixels. etc.)
- If a DVD-R/-RW disc has not been recorded properly in DVD Video format, it will not be playable.

Supported Formats (DivX)

This product only supports the following media formats. If both video and audio formats are not supported, the user may experience problems such as broken images or no sound.

Supported Video Formats

Format Supported Versions	
AVI	DivX3.11~DivX5.1
WMV	V1/V2/V3/V7

Supported Audio Formats

Format	Bit Rate	Sampling Frequency
MP3	80~320kbps	44.1khz
WMA	56~128kbps	44.18112
AC3	128~384kbps	44.1/48khz

- Aspect Ratio: This product supports up to 720x576 pixels. TV screen resolutions higher than 800 will not be supported.
- When you play a disc whose sampling frequency is higher than 48khz or 320kbps, you may experience shaking on the screen during playback.
- Sections with a high frame rate might not be played while playing a DivX file.
- Since this product only provides encoding formats authorized by DivX Networks, Inc., a DivX file created by the user might not play.

Notes on USB connection

Supported devices: USB storage media, MP3 player, digital camera


- If a folder or file name is longer than 10 characters, it may not properly display or operate.
- 2) A subtitle file bigger than 300KB may not be properly displayed.
- 3) A certain USB/digital camera device, USB card reader is not supported.
- 4) FAT16 and FAT32 file systems are supported.
- Photo (JPEG), music (MP3, WMA) and video file should have their names in Korean or English.
 Otherwise, the file may not played.
- Connect directly to the product's USB port.
 Connecting through another cable may raise problems with USB compatibility.
- Inserting more than one memory device to a multi-card reader may not operate properly.
- 8) PTP protocol for digital camera is not supported.
- Do not disconnect USB device during a "Reading" process.
- 10) Bigger the image resolution, the longer the delay to displaying.
- DRM applied MP3/WMA or video files downloaded from a commercial site are not played back.
- 12) External HDD device is not supported.
- 13) The maximum current supported by the USB port for an external device is 500 mA (at 5V DC).
- 14) Supported file formats

Format	Still Picture	Music		Movie	
File name	JPG	MP3	WMA	WMV	DivX
File extension	JPG .JPEG	.MP3	.WMA	.WMV	.AVI
Bit rate	-	80~320 kbps	56~128 kbps	4Mbps	4Mbps
Version	-	1	V8	V1,V2, V3,V7	DivX3.11~ DivX5.1
Pixel	640x480	-	-	720	0x576
Sampling Frequency	-	44.1kHz	44.1kHz	44.1KH	lz~ 48KHz

Getting Started

Description


Front Panel



1	DISC TRAY	Insert disc here.
2	DISPLAY	Displays the playing status, time, etc.
3	USB PORT	Connect here and play files from external USB storage devices such as MP3 players, USB flash memory, etc. The USB memory that requires high power (more than 500mA at 5V) may not be supported.
4	OPEN/CLOSE BUTTON ()	Opens and closes the disc tray.
5	FUNCTION BUTTON ()	The mode switches as follows : $DVD/CD \rightarrow AUX \rightarrow USB \rightarrow FM$
6	STOP BUTTON ()	Stops disc playback.
7	PLAY / PAUSE BUTTON ()	Plays a disc or pauses playback.
8	VOLUME CONTROL BUTTON (,)	Volume adjustment.
9	POWER BUTTON (也)	Turns the product on and off.
10	REMOTE CONTROL SENSOR	Detects signals from the remote control.
11	MIC JACKS	Connects to the microphone.

10 English


Rear Panel



1	FA NET (Only for Service)	Used for the service repair.
2	SPEAKERS OUTPUT CONNECTORS	Connect the front, center, surround speakers and subwoofer.
3	AUX IN JACKS	Connect to the 2CH Analog output of an external device (such as a VCR).
4	VIDEO OUT JACK	Connect your TV's Video Input jack (VIDEO IN) to the VIDEO OUT jack.
5	COMPONENT VIDEO OUTPUT JACKS	Connect a TV with Component video inputs to these jacks.
6	FM ANTENNA JACK	Connect the FM antenna.

Remote control

Tour of the Remote Control




^{*} Battery size: AAA

meters) in a straight line.

Connections

This section involves various methods of connecting the product to other external components. Before moving or installing the product, be sure to turn off the power and disconnect the power cord.

Connecting the Speakers



Position of the product

Place it on a stand or cabinet shelf, or under the TV stand.

Selecting the Listening Position

The listening position should be located about 2.5 to 3 times the distance of the TV's screen size away from the TV.

Example: For 32" TV's 2~2.4m For 55" TV's 3.5~4m

Front Speakers D B	Place these speakers in front of your listening position, facing inwards (about 45°) toward you. Place the speakers so that their tweeters will be at the same height as your ear. Align the front face of the front speakers with the front face of the center speaker or place them slightly in front of the center speakers.
Center Speaker C	It is best to install it at the same height as the front speakers. You can also install it directly over or under the TV.
Surround Speakers SL SR	Place these speakers to the side of your listening position. If there isn't enough room, place these speakers so they face each other. Place them about 60 to 90cm above your ear, facing slightly downward.
	* Unlike the front and center speakers, the surround speakers are used to handle mainly sound effects and sound will not come from them all the time.
Subwoofer SW	The position of the subwoofer is not so critical. Place it anywhere you like.

CAUTION


- Do not let children play with or near the speakers. They could get hurt if the speaker falls.
- Keep the subwoofer out of the reach of children so as to prevent them from inserting their hands or alien substances into the duct (hole) of the subwoofer.
- Do not hang the subwoofer on the wall through the duct (hole).

[®] NOTE

If you place a speaker near your TV set, screen colour may be distorted because of the magnetic field generated by the speaker. If this occurs, place the speaker away from your TV set.


Connections


Speaker Components



Connecting the wall mount


- Prepare screws (not supplied) that are suitable for the hole on the back of each speaker.
 See the illustrations below.
- **2.** Fasten the screws to the wall, then hang the speaker on the wall.





Connecting The Speakers


1. Connect the connecting plugs to the back of the product by matching the colours of the speaker plugs to the speaker jacks.



14 English

Connecting the Video Out to your TV

Choose one of the two methods for connecting to a TV.



METHOD 1: Component (Progressive Scan) Video

If your television is equipped with Component Video inputs, connect a Component video cable(not supplied) from the COMPONENT OUT (PR, PB and Y) jacks on the back of the product to the Component Video Input jacks on your TV.

METHOD 2: Composite Video

Connect the supplied Video cable from the VIDEO OUT jack on the back of the product to the VIDEO IN jack on your TV.

[®] NOTE

- When the Progressive scan mode is selected, the VIDEO output does not feed any signals.
- This product operates in Interlace scan mode 480i(576i) for component/composite output.
- After making the video connection, set the Video input source on your TV to match the corresponding Video output mode on your product.
 - Turn this product on first before you set the video input source on your TV. See your TV owner's manual for more information on how to select the TV's Video Input source.

! CAUTION

Do not connect the unit through a VCR. Video signals fed through VCRs may be affected by copyright protection systems and the picture will be distorted on the television.


Connections

P.SCAN(PROGRESSIVE SCAN) FUNCTION

Unlike regular Interlace Scan, in which two fields of picture information alternate to create the entire picture (odd scan lines, then even scan lines), Progressive Scan uses one field of information (all lines displayed in one pass) to create a clear and detailed picture without visible scan lines.

- 1. Press STOP button.
 - If playing a disc, press the STOP button twice so that "STOP", appears on the display.
- 2. Press and hold P.SCAN button on the remote control for over 5 seconds.
 - Pressing and holding the button for over 5 seconds will select "P.SCAN" and "I.SCAN" alternately.
 - When you select P.SCAN, "P.SCAN" will appear on the display.
 - To set P.Scan mode for DivX discs, press the P.SCAN button on the remote control for more than 5 seconds with no disc in the unit ("NO DISC" on the display), then load the DivX disc and play.

Connecting the FM Antenna




- 1. Connect the FM antenna supplied to the FM Antenna jack.
- 2. Slowly move the antenna wire around until you find a location where reception is good, then fasten it to a wall or other rigid surface.

[®] NOTE

This product does not receive AM broadcasts.



Connecting Audio from External Components



VCR

AUX: Connecting an External Analog Component

Analog signal components such as a VCR.

- 1. Connect AUX IN (Audio) on the back of the product to the Audio Out of the external Analog component.
 - Be sure to match the colors of the connecting jacks.
- 2. Press the FUNCTION button to select AUX input.
 - The mode switches as follows :
 DVD/CD → AUX → USB → FM



You can connect the Video Output jack of your VCR to the TV, and connect the Audio Output jacks of the VCR to this product.

Connecting Microphone

You can enjoy the feeling of a karaoke bar in the comfort of your home.


Watch the video and sing along the lyrics displayed on the TV screen against the accompaniment.


- 1. Connect the microphone to the MIC jack on the front of the product. You can connect up to two microphones.
- 2. Press the MIC VOL button to adjust the volume of the microphone.
- 3. Press the ECHO button to adjust the echo level of the microphone.
- 4. During the playback, press the KEYCON button, then press the (#/b) button. Each time the (#) button is pressed, the key is increased, and each time the (b) button is pressed, the key is decreased.
- Press the MY KARAOKE button to suppress the Vocal. Each time the button is pressed, the selection is changed as follows: Maximum Reduction → Minimum reduction → Original vocals.



- If you hear strange noises (squealing or howling) while using the Karaoke feature, move the microphone away from the speakers. Turning down the microphone's volume or the speaker volume is also effective.
- The microphone does not operate in the AUX and TUNER mode.
- When Speaker Selection is set to TV Speaker, The Microphone is not available
- After setting my karaoke or the keycon, PLII/S.VOL/P.BASS/DSP(EQ)/GIGA does not work.
- MY KARAOKE function doesn't work in DIVX state. KEYCON function doesn't work in DIVX/USB/MP3/WMA state.
- After the stop operation, the setting of my karaoke and keycon will disappear.







English 17

Before Starting (Initial Settings)

1. Press the POWER button when it is plugged in TV for the first time. Initial Settings screen will be displayed.



- 2. Press the ▲ ▼ buttons to select the desired language, then press the ENTER button.
- 3. Press the ▲ ▼ buttons to select desired TV Aspect, then press the **ENTER** button.

NOTE

- If you have not selected a preferred language in the initial settings, you will see a language selection window next time you turn on the product.
- Your language selection will apply to all menus: On-Screen Menu, Disc Menu, Audio, Subtitle.
- If you want to move to the previous screen, press the A(PREVIOUS) or RETURN button.
- Once you select a menu language, you can change it by pressing the STOP (II) button on the remote control or the main set for more than 5 seconds in no disc state.
- When the Initial Settings screen does not appear, refer to the Initial Settings. (see page 20)

Setting the Setup menu

The access step may differ depending on the selected menu. The GUI (Graphical User Interface) in this manual may differ, depending on the firmware version.



- HOME BUTTON: Display the home menu.
- **RETURN** BUTTON: Return to the previous 0 setup menu.

ENTER / DIRECTION BUTTON

- Move the cursor and select an item. 8 Select the currently selected item. Confirm the setting.
- 4 **EXIT** BUTTON: Exit the setup menu.



- 1. Press the **POWER** button.
- 2. Press the ◀▶ buttons to select Settings, then press the **ENTER** button.
- 3. Press the ▲▼ buttons to select the desired menu, then press the ENTER button.
- 4. Press the ▲▼ buttons to select the desired sub-menu, then press the **ENTER** button.
- 5. Press the ▲▼ buttons to select the desired item, then press the **ENTER** button.
- 6. Press the EXIT button to exit the setup menu.

Display

You can configure various display options such as the TV Aspect, Resolution, etc.

TV Aspect

Depending on the type of television you have, you may want to adjust the screen setting.

4:3 Pan-Scan



Select when you want to see the 16:9 video supplied by the DVD without the black bars on top and bottom, even though you have a TV with a 4:3 ratio screen(extreme left and right portion of the movie picture will be cut off).

4:3 Letter Box



Select when you want to see the total 16:9 ratio screen DVD supplies, even though you have a TV with a 4:3 ratio screen. Black bars will appear at the top and bottom of the screen.

16:9 Wide



You can view the full 16:9 picture on vour widescreen TV.

[®] NOTE

- If a DVD is in the 4:3 ratio, you cannot view it in the wide screen.
- Since DVD discs are recorded in various image formats, they will look different depending on the software, the type of TV, and the TV aspect ratio setting.

Video Out Signal(option)

Different countries apply different TV standard. You can select from NTSC or PAL.

- NTSC: You can select the NTSC video format
- PAL: You can select the PAL video format.

Audio

Speaker Setting

Speaker Size

You can set the Speaker Size of the Center and Surround Speakers, as well as Test Tone in this mode.




- For the Front, the mode is set to Small.
- For the Subwoofer, the mode is set to Present.
- For the Center and Surround, you can switch the mode to Small or None.
 - Small: Select this when using the speakers.
 - None: Select this when no speaker is connected.

NOTE

The speaker mode may vary depending on the Dolby Pro Logic and Stereo settings.

Sound Edit

You can adjust the balance and level for each speaker.



Press the ▲▼ buttons to select and adjust the desired speaker.

Press the ◀▶ buttons to adjust the settings.

Adjusting Front/Surround Bal.

- You can select between 0 and -6.
- The volume decreases as you move closer to -6.

Adjusting Center/Surround/Subwoofer Level

- The volume level can be adjusted in steps from +6dB to -6dB.
- The sound gets louder as you move closer to +6dB and quieter as you get closer to -6dB.

Setup

Delay Time

If the speakers cannot be placed at equal distances from the listening position, you can adjust the delay time of the audio signals from the Center and Surround speakers. You can also set the Test Tone in this mode.

Setting up the Speaker Delay Time

When 5.1CH Surround Sound is played, you can enjoy the best sound if the distance between you and each speaker is the same.

Since the sounds arrive at the listening position at different times depending on the placement of speakers, you can adjust this difference by adding a delay effect to the Center and Surround Speakers.



Test Tone



Use the Test Tone feature to check the speaker connections.

- Press the ◀▶ buttons to select On.
- The test tone will be sent to Front Left → Center
 → Front Right → Surround Right → Surround
 Left → Subwoofer in order.

To stop the test tone, press the **ENTER** button.

DRC (Dynamic Range Compression)

This feature balances the range between the loudest and quietest sounds. You can use this function to enjoy Dolby Digital sound when watching movies at low volume at night.

• You can select either Full, 6/8, 4/8, 2/8, off.

AUDIO SYNC

Video and audio sync may not match with digital TV. If this occurs, adjust the audio delay time to match the video

 You can set the audio delay time between 0 mSec and 300 mSec. Set it to the optimal status.

User EQ

You can configure the equalizer settings manually to your preference.



Karaoke Scoring

Karaoke score display can be toggled On or Off.

- Off: Turns off the karaoke score display.
- On : After the singing, the score is displayed on the screen.



In USB/DIVX state,karaoke scoring does not work.

System

Initial Settings

By using the Initial Settings, you can set the language and TV aspect.

DivX(R) Registration

View DivX(R) VOD Registration Code to purchase and play DivX(R) VOD content.

Language

You can select the language you prefer for on-screen menu. disc menu. etc.

OSD Language	Select the language for the on-screen displays.
Disc Menu	Select the language for the disc menu displays.
Audio	Select the language for disc audio.
Subtitle	Select the language for disc subtitles.

- * To select a language that does not appear in the menu, select OTHERS in the Disc Menu, Audio and Subtitle, and enter the language code of your country (see page 31).
- You cannot select OTHERS in the OSD Language



■ The selected language will only appear if it is supported on the disc.

Security

The Parental Lock function works in conjunction with DVDs that have been assigned a rating, which helps you control the types of DVDs that your family watches. There are up to 8 rating levels on a disc.

Parental Rating

Select the rating level you want to set.

A larger number indicates that the program is intended for adult use only. For example, if you select up to Level 6, discs that contain Level 7, 8 will not play.

Enter the password and then press the **ENTER** button.

- The password is set to "0000" by default.
- Once the setup is complete, you will be taken to the previous screen.

Change Password

Select Change and enter the 4-digit password to set the parental lock using the number buttons on the remote control.

If you forgot your password

- Remove the disc.
- 2. Press and hold the STOP (

) button on the remote control for 5 seconds or more. All settings will revert to the factory settings.

Support

Product Information

Provide the product information such as Model code. Softrware Version, etc.

Disc Playback

- Press the OPEN/CLOSE (▲) button.
- 2. Place a disc gently into the tray with the disc's label facing up.
- 3. Press the OPEN/CLOSE (♠) button to close the disc tray.

[®] NOTE

- Resume function: When you stop disc play, the product remembers where you stopped, so when you press PLAY button again, it will pick up where you left off. (This function works only with DVDs.)
 - Press the **STOP** button twice during playback to disable the Resume function.
- If no buttons are pressed on the product or remote control for more than 3 minutes when the product is in Pause mode, it will change to STOP mode.
- The initial screen may appear different, depending on the content of the disc.
- Pirated discs will not play in this product because they violate the CSS(Content Scrambling System: a copy protection system) recommendations.
- ※ Ø will appear when an invalid button is pressed.

TV Screen Saver/Power Saving Function

- If no button input is made for more than 5 minutes in Stop or Play(music) mode, the screen saver will get activated.
- If the product is left in the screen saver mode for more than 20 minutes, the power will automatically turn off. (Except during play a music)

Audio CD(CD-DA)/MP3/WMA Playback







- 1. Insert an Audio CD(CD-DA) or an MP3 Disc into the disc trav.
 - For an Audio CD, the first track will be played automatically.
 - Press the I buttons to move to the previous/next track.
 - For the MP3/WMA disc, press the ◀▶ buttons to select Music, then press the **ENTER** button.
 - Press the ▲▼◀▶ buttons to select a desired file and press the ENTER button.
 - Press the **◄>>** buttons to move to the previous/next pages.
- 2. Press the STOP (■) button to stop playback.


[®] NOTE

- Some MP3/WMA-CDs may not play, depending on the recording mode.
- Table of contents of a MP3-CD varies depending on the MP3/WMA track format recorded on the disc.
- The WMA-DRM files cannot be played.
- When MP3/WMA/CD playing, number key doesn't work.

JPEG File Playback

Images captured with a digital camera or camcorder, or JPEG files on a PC can be stored on a CD and then played back with this product.

- 1. Insert a JPEG disc on the disc tray.
- 2. Press the ◀▶ buttons to select Photo, and then press the **ENTER** button.
- 3. Press the ▲▼ buttons to select the folder you want to play, and then press the **ENTER** button.
- 4. Press the ▲ ▼ buttons to select the photo you want to play, and then press the ENTER button.
 - The selected file will play and slide show will
 - To stop slide show, press the PAUSE (II) button.
 - You can view the previous/next file by pressing the ◀,▶ buttons during the slideshow mode.



Rotate Function



Press the GREEN(B) or YELLOW(C) button during the PAUSE mode.

- GREEN(B) Button: Rotate 90° counterclockwise.
- YELLOW(C) Button: Rotate 90° clockwise.



The maximum resolutions supported by this product are 5120 x 3480 (or 19.0 MPixel) for standard JPEG files and 2048 x 1536 (or 3.0 MPixel) for progressive image files.

Using the Playback Function

Forward/Reverse Search










Press the ◀▶ buttons for Search Function.





- No sound is played in search mode.
- The playback search produces sound only when searching at ▶1 and ▶2 speed. This function is available only for the CD-DA.

Skipping Scenes/Songs









Press the I◀►►I buttons.

- Each time the button is pressed during playback. the previous or next chapter, track or directory (file) will be played.
- · You cannot skip chapters consecutively.

Slow Motion Play





Press the PAUSE (II) button and then ▶ button for Slow Motion play.









- No sound is heard during slow playback.
- Reverse slow playback does not work.

Step Motion Play





Press the **PAUSE** button repeatedly.

• The picture moves forward one frame each time the button is pressed during playback.

NOTE

No sound is heard during step motion playback.

5 Minute Skip function



During playback, press the ◀,▶ button.

- Playback skips 5 minutes forward whenever you press the ▶ button.
- Playback skips 5 minutes backward whenever you press the ◀ button.



This function is available only for the DivX that contains time information.

Using the Disc Menu



You can view the menus for the audio language, subtitle language, profile, etc.

1. During playback, press the DISC MENU button on the remote control.



2. Press the ▲▼◀► buttons to make the desired selection, then press the **ENTER** button.

NOTE


Depending on the disc, menu setup items may vary and this menu may not be available.

Basic Functions

Using the Title Menu

For DVDs containing multiple titles, you can view the title of each movie.

- During playback, press the TITLE
- button.





Depending on the disc, menu setup items may vary and this menu may not be available.

Repeat Playback










DVD/DivX Repeat

You can repeat the title, chapter or the section(A-B Repeat) of the DVD/DivX.



- 1. During DVD/DivX playback, press the **REPEAT** button on the remote control.
- 2. Press the ▲▼ buttons to select a desired repeat mode, then press the ENTER button.
- 3. Press the ▲ ▼ buttons to select OFF to return to normal play, then press the ENTER button.



CD/MP3 Repeat

1. During the CD/ MP3 playback, press the **REPEAT** button repeatedly to select the repeat mode vou want.



± → CT) → ŒP → **⊐**⊄ → ŒB

(Repeat Off → Repeat Track → Repeat All → Random → Repeat Section A-B)



⇒ → ○ → ○ → △ → **>**

(Repeat Off → Repeat Track→ Repeat Dir (Directory) → Repeat All → Random)

A-B Repeat Playback





You can repeatedly play back a designated section of a DVD or CD.

- 1. During the DVD disc or CD playback, press the REPEAT button on the remote control.
- 2. For DVD, press the ▲▼ buttons to select A-. For CD press the **REPEAT** button repeatedly until AB appears.
- 3. Press the ENTER button at the point where you want repeat play to start (A).
- 4. Press the ENTER button at the point where you want repeat play to stop (B).
- 5. To return to normal playback, For DVD, press the **REPEAT** button ,then press the ▲▼ buttons to select to OFF. For CD, press the **REPEAT** button to select to \Rightarrow .



- The A-B Repeat function does not operate with DivX, MP3 or JPEG discs.
- Repeat function is not available during CD/DVD disc is played if karaoke scoring is set to on.

Displaying Disc Information









1. During playback, press the TOOLS button on the remote control



- 2. Press the ▲▼ buttons to select the desired item.
- 3. Press the ◀▶ buttons to make the desired setup change and then press the ENTER button.
 - You may use the number buttons of the remote control to control some items.
- 4. To make Disc information disappear, press the TOOLS button again.

№ NOTE

- If you are playing contents from the tools menu, some functions may not be enabled depending on the disc.
- You can also select Dolby Digital or Pro Logic, depending on the disc.
- Some tools menus may differ depending on discs and

TOOLS menu

- Title(→): To access the desired title when there is more than one in the disc. For example, if there is more than one movie on a DVD, each movie will be identified as a Title.
- Chapter(♣): Most DVD discs are recorded in chapters so that you can quickly find a specific chapter.
- Playing time(②): Allows playback of the film from a desired time. You must enter the starting time as a reference. The time search function does not operate on some discs.
- Audio(): Refers to the film's soundtrack language. A DVD Disc can contain up to 8 audio languages.
- Subtitle(): Refers to the subtitle languages available in the disc. You will be able to choose the subtitle languages or, if you prefer, turn them off from the screen. A DVD Disc can contain up to 32 subtitle languages.
- Angle(🙈): When a DVD contains multiple angles of a particular scene, you can use the Angle function.

Selecting the Audio Language





- 1. Press the TOOLS button.
- 2. Press the ▲▼ buttons to select AUDIO () display.
- 3. Press the ◀▶ buttons to select the desired audio language.
 - Depending on the of languages on a DVD disc, a different audio language is selected each time the button is pressed.

Selecting the Subtitle Language





- 1. Press the TOOLS button.
- 2. Press the ▲▼ buttons to select SUBTITLE (□) display.

Basic Functions

- Press the ◀► buttons to select the desired subtitle language.
 - Depending on the languages on a DVD disc, a different subtitle language is selected each time the button is pressed.



 Depending on the disc, the Subtitle and Audio Language functions may not be available.

Caption Function



- You must have some experience with video extraction and editing in order to use this feature properly.
- To use the caption function, save the caption file (*.smi) in the same file name as that of the DivX media file (*.avi) within the same folder.
 Example. Root Samsung_007CD1.avi Samsung_007CD1.smi
- Up to 100 alphanumeric characters or 50 East Asian characters (2 byte characters such as Korean and Chinese) for the file name.
- The subtitle of DivX files are *.smi, *.sub, *.srt over 148 kbyte is not supported.

Angle Function



This function allows you to view the same scene in different angles.

- 1. Press the TOOLS button.
- 2. Press the ▲▼ buttons to select ANGLE (alpha) display.
- **3.** Press the **◄►** buttons to select the desired angle.



The Angle function works only with discs on which multiple angles have been recorded.

DIMMER

You can adjust the brightness of the display on the main unit.

Press the **DIMMER** button.



Sound Mode

PBASS

The P.BASS function provides a bass boost to reinforce the low frequencies.

AUDIO UPSCALE PRASS PRASS

The MP3 ENHANCE function provides better sound quality by upscaling the sampling frequency.

Press the P.BASS button.

2 Channel LPCM source	POWER BASS ON → POWER BASS OFF
	MP3 ENHANCE ON →
MP3 file	POWER BASS ON →
	POWER BASS OFF




- The P.BASS function is only available with 2 channel LPCM sources such as MP3, DivX, CD and WMA.
- The MP3 Enhancement function is only available MP3 file.

S.VOL (SMART VOLUME)

This will regulate and stabilize the volume level against a drastic volume change when changing channels or during a scene transition.

Press the S.VOL button.

• Each time the button is pressed, the selection changes as follows:





GIGA

The GIGA Sound Function amplifies bass and improves bass twice as much for you to appreciate powerful real sound. The GIGA Sound feature will be applied only to the subwoofer.

Press the GIGA button.



- The GIGA Sound works when in 2-channel LPCM mode only.
- GIGA doesn't work when connecting the microphone to the MIC jack.

S/W LEVEL

You can also press the S/W LEVEL button on the remote control and use the ◀ or ▶ buttons to adjust the level of subwoofer.

Press the S/W LEVEL button.

DSP (Digital Signal Processor)/EQ

- DSP (Digital Signal Processor): DSP modes have been designed to simulate different acoustic environments.
- · EQ: You can select POPS, JAZZ. ROCK, or USER to optimize the sound for the genre of music you are playing.

Press the DSP/EQ button.



MOVIE	Provides the feeling of a movie cinema.
CHURCH	Provides the feeling of being in a grand church.
0FF	Select this for normal listening.

- The DSP/EQ function is only available in Stereo mode.
- The DSP/EQ function is not available while playing AC3 signal in 2.1 channel mode.
- Some regional EQs are special, such as India, Africa, and so on. Please refer to the display of actual product to operate.

Dolby Pro Logic II Mode

You can select the desired Dolby Pro Logic II audio mode.

Press the DO PL II button.



	•			
MUSIC	When listening to music, you can experience sound effects as if you are listening to the actual performance.			
MOVIE	Adds realism to the movie soundtrack.			
PROLOG	You can listen to a 2CH sound source in 5.1CH surround sound with all speakers active. - A specific speaker(s) may not be output depending on the input signal.			
MATRIX	You will hear multi-channel surround sound.			
STERE0	Select this to listen to sound from the front left and right speakers and the subwoofer only.			

NOTE

- When selecting Pro Logic II mode, connect your external device to the AUDIO INPUT jacks (L and R) on the product. If you connect to only one of the inputs (L or R), you cannot listen to surround sound.
- The Pro Logic II function is only available in Stereo mode...

Basic Functions

Listening to Radio

Using buttons on the Remote Control

- 1. Press the FUNCTION button to select FM.
- 2. Tune in to the desired station.
 - Preset Tuning 1: You must first add a desired frequency as a preset. Press the STOP (■) button to select PRESET and then press the TUNING/CH (^~) button to select the preset station
 - Manual Tuning: Press the STOP (■) button to select MANUAL and then press the TUNING/CH (^) button to tune in to a lower or higher frequency.
 - Automatic Tuning: Press the STOP (■) button
 to select MANUAL and then press and hold the
 TUNING/CH (^ ``) button to automatically
 search the band.

- 5. Press the TUNER MEMORY button again.
 - Press the TUNER MEMORY button before number disappears from the display.
 - Number disappears from the display and the station is stored in memory.
- **6.** To preset another station, repeat steps 2 to 5.

Setting Mono/Stereo

Press the MO/ST button.

- Each time the button is pressed, the sound switches between STEREO and MONO.
- In a poor reception area, select MONO for a clear, interference-free broadcast.



Presetting Stations

Example: Presetting FM 89.10 in the memory


- 1. Press the FUNCTION button to select FM.
- 2. Press the TUNING/CH (^~) button to select <89.10>
- 3. Press the TUNER MEMORY button.
 - Number flashes on the display.
- **4.** Press the **TUNING/CH** (**^ ∨**) buttons to select preset number.
 - You can select between 1 and 15 presets.



USB Function

Playing Media Files using the **USB Host Feature**

You can enjoy media files such as pictures, movies and music saved on an MP3 player, USB memory stick or digital camera in high quality video with 5.1 channel sound by connecting the storage device to the USB port of the product.



- 1. Connect the USB device to the USB port on the front panel of the product.
- 2. Press the **FUNCTION** button to select USB.
 - USB appears on the display screen and then disappears.
- 3. Press the ◀▶ buttons to select Videos. Photos or Music.
 - Select a file to play.

Safe USB Removal

To prevent damage to the memory stored in the USB device, perform safe removal before disconnecting the USB cable.

- Press the YELLOW(C) button.
 - REMOVE will appear on the display.
- · Remove the USB cable.

[®] NOTE

- To listen to your music files with 5.1 channel sound, you must set the Dolby Pro Logic II mode to Matrix. (See page 27)
- Remove the USB cable from the USB port slowly. Otherwise, it may cause damage to the USB port.

USB Recording

While playing CD-DA (Compact Disc Digital Audio) using the USB Recording function or listening to the FM radio or receiving audio source from an external device, you can record the audio source in the USB memory.

Ex) USB recording of CD-DA audio contents

- 1. Connect the USB device to your product.
- 2. Insert the CD-DA disc into the CD tray.
- 3. Press the USB REC button on the remote control.
 - To start recording the current track, press the USB REC button on the remote control while the system is playing a track or stopped temporarily.
 - To record the entire CD, press and hold the USB REC button on the remote control.
 - "FULL RECORDING" appears on the display and recording starts.
- 4. Press the STOP (■) button to stop recording.
 - When USB recording of a CD is completed. you will find a new folder named "RECORDING" in the USB drive. The contents will be saved in the folder in the MP3
 - · When USB recording of FM radio or AUX source is completed, you will find a new folder named "TUNER RECORDING or AUX RECORDING" in the USB drive. The contents. will be saved in the folder in the MP3 format.

NOTE

- Do not disconnect the USB connection or the power cable during the USB Recording. Otherwise, it may cause damage
 - To stop USB Recording, press the STOP button and disconnect the USB device after the system stops playing the CD completely.
- If you disconnect the USB connection during the USB Recording, the system will turn off and you will not be able to delete the recorded file.
- If you connect the USB device to the system while it is playing a CD, the system stops temporarily and will play again.
- If the recording duration is less than 5 seconds, a recording file may not be created.
- USB Recording works only if the USB device is formatted in the FAT file system. (The NTFS file system is not supported.)
- The audio signal will not be output during USB recording of the CD in no MIC connecting state. Otherwise, The audio signal will be output during USB recording of the CD in MIC connecting state.
- When Speaker selection is set to TV Speaker, the USB Recording function is not supported.
- Disconnect the microphone to the set during recording, recording will be stopped.
- The set will be started X3 recording when the Microphone doesn't connect to the set.
- Any button except Stop /Volume/Mute/ Mic Volume/Echo button doesn't work during USB recording.

Other Information

Troubleshooting

Refer to the chart below when this product does not function properly. If the problem you are experiencing is not listed below or if the instruction below does not help, turn off the product, disconnect the power cord, and contact the nearest authorized dealer or Samsung Electronics Service Centre.

Symptom	Check/Remedy			
I cannot eject the disc.	Is the power cord plugged securely into the outlet? Turn off the power and then turn it back on.			
Playback does not start.	Check the region number of the DVD. DVD discs purchased from abroad may not be playable. CD-ROMs and DVD-ROMs cannot be played on this product. Make sure that the rating level is correct.			
Playback does not start immediately when the Play/Pause button is pressed.	Are you using a deformed disc or a disc with scratches on the surface? Wipe the disc clean.			
Sound is not produced.	No sound is heard during fast playback, slow playback, and step motion playback. Are the speakers connected properly? Is the speaker setup correctly customized? Is the disc severely damaged?			
Sound can be heard only from a few speakers and not all 6.	 On certain DVD discs, sound is output from the front speakers only. Check if the speakers are connected properly. Adjust the volume. When listening to a CD, radio or TV, sound is output to the front speakers only. Select "PROLOG" by pressing DX PL II (Dolby Pro Logic II) on the remote control to use all six speakers. 			
Dolby Digital 5.1 CH Surround Sound is not produced.	 Is there "Dolby Digital 5.1 CH" mark on the disc? Dolby Digital 5.1 CH Surround Sound is produced only if the disc is recorded with 5.1 channel sound. Is the audio language correctly set to Dolby Digital 5.1-CH in the information display? 			
The remote control does not work.	Is the remote control being operated within its operation range of angle and distance? Are the batteries drained? Have you selected the correct mode (RECEIVER DVD/TV)?			
 Disc is rotating but no picture is produced. Picture quality is poor and picture is shaking. 	Is the TV power on? Are the video cables connected properly? Is the disc dirty or damaged? A poorly manufactured disc may not be playable.			
Audio language and subtitles do not work.	Audio language and subtitles will not work if the disc does not contain them.			
The Disc/Title menu screen does not appear even when the Disc/Title function is selected.	Are you using a disc that does not contain menus?			
Aspect ratio cannot be changed.	You can play 16:9 DVDs in 16:9 WIDE mode, 4:3 LETTER BOX mode, or 4:3 PAN SCAN mode, but 4:3 DVDs can be seen in 4:3 ratio only. Refer to the DVD disc jacket and then select the appropriate function.			

8

Symptom	Check/Remedy		
The product is not working. (Example: The power goes out or the front panel key doesn't work or a strange noise is heard.)	 Press and hold the STOP (
 The product is not working normally. 	Do not use this unless necessary.		
The rating level password has been forgotten.	 While "NO DISC" message appears on the display of the product, press and hold the remote control's STOP (
Can't receive radio broadcast.	Is the antenna connected properly? If the antenna's input signal is weak, install an external FM antenna in an area with good reception.		

Language code list

Enter the appropriate code number for OTHERS in the Disc Menu, Audio and Subtitle. (See page 21).

Code	Language	Code	Language	Code	Language	Code	Language	Code	Language	Code	Language
1027	Afar	1142	Greek	1239	Interlingue	1345	Malagasy	1482	Kirundi	1527	Tajik
1028	Abkhazian	1144	English	1245	Inupiak	1347	Maori	1483	Romanian	1528	Thai
1032	Afrikaans	1145	Esperanto	1248	Indonesian	1349	Macedonian	1489	Russian	1529	Tigrinya
1039	Amharic	1149	Spanish	1253	Icelandic	1350	Malayalam	1491	Kinyarwanda	1531	Turkmen
1044	Arabic	1150	Estonian	1254	Italian	1352	Mongolian	1495	Sanskrit	1532	Tagalog
1045	Assamese	1151	Basque	1257	Hebrew	1353	Moldavian	1498	Sindhi	1534	Setswana
1051	Aymara	1157	Persian	1261	Japanese	1356	Marathi	1501	Sangro	1535	Tonga
1052	Azerbaijani	1165	Finnish	1269	Yiddish	1357	Malay	1502	Serbo-Croatian	1538	Turkish
1053	Bashkir	1166	Fiji	1283	Javanese	1358	Maltese	1503	Singhalese	1539	Tsonga
1057	Byelorussian	1171	Faeroese	1287	Georgian	1363	Burmese	1505	Slovak	1540	Tatar
1059	Bulgarian	1174	French	1297	Kazakh	1365	Nauru	1506	Slovenian	1543	Twi
1060	Bihari	1181	Frisian	1298	Greenlandic	1369	Nepali	1507	Samoan	1557	Ukrainian
1069	Bislama	1183	Irish	1299	Cambodian	1376	Dutch	1508	Shona	1564	Urdu
1066	Bengali; Bangla	1186	Scots Gaelic	1300	Canada	1379	Norwegian	1509	Somali	1572	Uzbek
1067	Tibetan	1194	Galician	1301	Korean	1393	Occitan	1511	Albanian	1581	Vietnamese
1070	Breton	1196	Guarani	1305	Kashmiri	1403	(Afan) Oromo	1512	Serbian	1587	Volapuk
1079	Catalan	1203	Gujarati	1307	Kurdish	1408	Oriya	1513	Siswati	1613	Wolof
1093	Corsican	1209	Hausa	1311	Kirghiz	1417	Punjabi	1514	Sesotho	1632	Xhosa
1097	Czech	1217	Hindi	1313	Latin	1428	Polish	1515	Sundanese	1665	Yoruba
1103	Welsh	1226	Croatian	1326	Lingala	1435	Pashto, Pushto	1516	Swedish	1684	Chinese
1105	Danish	1229	Hungarian	1327	Laothian	1436	Portuguese	1517	Swahili	1697	Zulu
1109	German	1233	Armenian	1332	Lithuanian	1463	Quechua	1521	Tamil		
1130	Bhutani	1235	Interlingua	1334	Latvian, Lettish	1481	Rhaeto- Romance	1525	Tegulu		

Other Information

		Specifications					
	Weight	2.04 Kg					
0	Dimensions	430 (W) x 61 (H) x 230 (D) mm					
General	Operating Temperature Range	+5°C~+35°C					
	Operating Humidity Range	10 % to 75 %					
	Signal/noise ratio	60 dB					
FM Tuner	Usable sensitivity 10 dB						
	Total harmonic distortion	1%					
	DVD (Digital Versatile Disc)		Reading Speed: 3.49 ~ 4.06 m/sec. Approx. Play Time (Single Sided, Single Layer Disc): 135 min.				
Disc	CD . 10 cm (COMPACT DICC)	Reading Speed : 4.8		,			
DISC	CD : 12 cm (COMPACT DISC)	Maximum Play Time	: 74 min.				
	CD : 8cm (COMPACT DISC)	Reading Speed: 4.8	3 ~ 5.6 m/sec.				
	CD . OCH (CONFACT DISC)	Maximum Play Time	: 20 min.				
	Composite Video	480i(576i)	480i(576i)				
	Composito video	1 channel : 1.0 Vp-	p (75 Ω load)				
Video Output		480i(576i)					
	Component Video	Y : 1.0 Vp-p (75 Ω					
	·	Pr : 0.70 Vp-p (75					
		Pb : 0.70 Vp-p (75	12 load)				
	Front speaker output	35W x 2(3Ω)	35W x 2(3Ω)				
	Center speaker output	95W(3Ω)					
	Surround speaker output	35W x 2(3Ω)					
Amplifier	Subwoofer output	95W(3Ω)					
Amplillo	Frequency range	20Hz~20KHz	20Hz~20KHz				
	S/N Ratio	65dB					
	Channel separation	60dB	60dB				
	Input sensitivity (AUX)800mV						
	Speaker system		5.1ch speak	er system	1		
	——————————————————————————————————————	Front	Surround	Center	Subwoofer		
	Impedance	3 Ω	3 Ω	3 Ω	3 Ω		
	Frequency range	140Hz~20KHz	140Hz~20KHz	140Hz~20KHz	20Hz~160Hz		
	Output sound pressure level	86dB/W/M	86dB/W/M	86dB/W/M	88dB/W/M		
Speaker	Rated input	35W	35W	95W	95W		
	Maximum input	70W	70W	190W	190W		
	Dimensions (W x H x D)		Front/ Surround/ Center: 77 x 107 x 68 mm Subwoofer: 154 x 299 x 285 mm				
	Weights	Front: 0.3 Kg, C Surround : 0.32	Center : 0.34 Kg Kg, Subwoofer	: 2.89 Kg			

*: Nominal specification

- Samsung Electronics Co., Ltd reserves the right to change the specifications without notice.
- Weight and dimensions are approximate.
- Design and specifications are subject to change without prior notice.
- For the power supply and Power Consumption, refer to the label attached to the product.

OpenSSL License

The OpenSSL toolkit stays under a dual license, i.e. both the conditions of the OpenSSL License and the original SSLeay license apply to the toolkit. See below for the actual license texts. Actually both licenses are BSD-style Open Source licenses. In case of any license issues related to OpenSSL please contact openssl-core@openssl.org.

OpenSSL License

Copyright (c) 1998-2007 The OpenSSL Project. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3. All advertising materials mentioning features or use of this software must display the following acknowledgment: "This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit. (http://www.openssl.org/)"
- 4. The names "OpenSSL Toolkit" and "OpenSSL Project" must not be used to endorse or promote products derived from this software without prior written permission. For written permission, please contact openssl-core@openssl.org.
- 5. Products derived from this software may not be called "OpenSSL" nor may "OpenSSL" appear in their names without prior written permission of the OpenSSL Project.
- 6. Redistributions of any form whatsoever must retain the following acknowledgment: "This product includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (http://www.openssl. org/)"

THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT "AS IS" AND ANY EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT. INDIRECT. INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY. WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

This product includes cryptographic software written by Eric Young (eay@cryptsoft.com). This product includes software written by Tim Hudson (tjh@cryptsoft.com).

Original SSLeav License

Copyright (C) 1995-1998 Eric Young (eay@cryptsoft.com) All rights reserved.

This package is an SSL implementation written by Eric Young (eay@cryptsoft.com).

The implementation was written so as to conform with Netscapes SSL.

This library is free for commercial and non-commercial use as long as the following conditions are aheared to. The following conditions apply to all code found in this distribution, be it the RC4, RSA, lhash, DES, etc., code; not just the SSL code. The SSL documentation included with this distribution is covered by the same copyright terms except that the holder is Tim Hudson (tjh@cryptsoft.com).

OpenSSL License

Copyright remains Eric Young's, and as such any Copyright notices in the code are not to be removed. If this package is used in a product, Eric Young should be given attribution as the author of the parts of the library used. This can be in the form of a textual message at program startup or in documentation (online or textual) provided with the package.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- 1. Redistributions of source code must retain the copyright notice, this list of conditions and the following disclaimer.
- 2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- 3. All advertising materials mentioning features or use of this software must display the following acknowledgement:
- "This product includes cryptographic software written by Eric Young (eay@cryptsoft.com)"

The word 'cryptographic' can be left out if the rouines from the library being used are not cryptographic related :-).

4. If you include any Windows specific code (or a derivative thereof) from the apps directory (application code) you must include an acknowledgement: "This product includes software written by Tim Hudson (tjh@cryptsoft. com)"

THIS SOFTWARE IS PROVIDED BY ERIC YOUNG "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING. BUT NOT LIMITED TO. THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE. EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

The licence and distribution terms for any publically available version or derivative of this code cannot be changed. i.e. this code cannot simply be copied and put under another distribution licence [including the GNU Public Licence.]

Contact SAMSUNG WORLD WIDE

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care centre.

Area	Contact Centre 🖀	Web Site
 North Americ 		
Canada	1-800-SAMSUNG (726-7864)	www.samsung.com
Mexico	01-800-SAMSUNG (726-7864)	www.samsung.com
U.S.A	1-800-SAMSUNG (726-7864)	www.samsung.com
 Latin America 		
Argentine	0800-333-3733	www.samsung.com
Brazil	0800-124-421 / 4004-0000	www.samsung.com
Chile	800-SAMSUNG (726-7864)	www.samsung.com
Colombia	01-8000112112	www.samsung.com
Costa Rica	0-800-507-7267	www.samsung.com
Dominica	1-800-751-2676	www.samsung.com
Ecuador	1-800-10-7267	www.samsung.com
El Salvador	800-6225	www.samsung.com
Guatemala Honduras	1-800-299-0013 800-7919267	www.samsung.com
Jamaica	1-800-234-7267	www.samsung.com
Nicaragua	00-1800-5077267	www.samsung.com
Panama	800-7267	www.samsung.com
Peru	0-800-777-08	www.samsung.com
Puerto Rico	1-800-682-3180	www.samsung.com www.samsung.com
Trinidad &		www.samsung.com
Tobago	1-800-SAMSUNG (726-7864)	www.samsung.com
Venezuela	0-800-100-5303	www.samsung.com
■ Europe	0 000 100 0000	WWW.cambang.com
Albania	42 27 5755	_
	0810 - SAMSUNG (7267864.	
Austria	€ 0.07/min)	www.samsung.com
Belgium	02-201-24-18	www.samsung.com/ be (Dutch) www.samsung.com/ be fr (French)
Bosnia	05 133 1999	-
Bulgaria	07001 33 11	www.samsung.com
Croatia	062 SAMSUNG (062 726 7864)	www.samsung.com
	800-SAMSUNG (800-726786)	J
Czech	Samsung Zrt., česká organizační složka, Oasis Florenc, Soko- lovská394/17, 180 00, Praha 8	www.samsung.com
Denmark	70 70 19 70	www.samsung.com
Finland	030 - 6227 515	www.samsung.com
France	01 48 63 00 00	www.samsung.com
Germany	01805 - SAMSUNG (726-7864 € 0,14/Min)	www.samsung.com
Hungary	06-80-SAMSUNG (726-7864)	www.samsung.com
Italia	800-SAMSUNG (726-7864)	www.samsung.com
Kosovo	+381 0113216899	-
Luxemburg	261 03 710	www.samsung.com
Macedonia	023 207 777	-
Montenegro	020 405 888	-
Netherlands	0900-SAMSUNG (0900- 7267864) (€ 0,10/Min)	www.samsung.com
Norway	815-56 480	www.samsung.com
Poland	0 801 1SAMSUNG (172678) / 022-607-93-33	www.samsung.com
Portugal	80820-SAMSUNG (726-7864)	www.samsung.com
Rumania	1. 08010 SAMSUNG (72678) - doar din reţeaua Romtelecom, tarif local 2. 021.206.01.10 - din orice reţea, tarif normal	

Area	Contact Centre 🕿	Web Site		
Corbin	0700 Samsung (0700 726	Manay comound com		
Serbia	7864)	www.samsung.com		
Slovakia	0800-SAMSUNG (726-7864)	www.samsung.com		
Spain	902-1-SAMSUNG (902 172 678)	www.samsung.com		
Sweden	0771 726 7864 (SAMSUNG)	www.samsung.com		
Switzerland	0848-SAMSUNG (7267864, CHF 0.08/min)	www.samsung.com/ch www.samsung.com/ ch_fr/(French)		
U.K	0330 SAMSUNG (7267864)	www.samsung.com		
Eire	0818 717100	www.samsung.com		
Lithuania	8-800-77777	www.samsung.com		
Latvia	8000-7267	www.samsung.com		
Estonia	800-7267	www.samsung.com		
■ CIS				
Russia	8-800-555-55-55	www.samsung.com		
Georgia	8-800-555-555	-		
Armenia	0-800-05-555	-		
Azerbaijan	088-55-55-555	-		
Kazakhstan	8-10-800-500-55-500 (GSM: 7799)	www.samsung.com		
Uzbekistan	8-10-800-500-55-500	www.samsung.com		
Kyrgyzstan	00-800-500-55-500	www.samsung.com		
Tadjikistan	8-10-800-500-55-500	www.samsung.com		
Ukraine	0-800-502-000	www.samsung.ua www.samsung.com/ ua_ru		
Belarus	810-800-500-55-500	-		
Moldova	00-800-500-55-500	-		
Asia Pacific				
Australia	1300 362 603	www.samsung.com		
New Zealand	0800 SAMSUNG (0800 726 786)	www.samsung.com		
China	400-810-5858 / 010-6475 1880	www.samsung.com		
Hong Kong	(852) 3698 4698	www.samsung.com/hk www.samsung.com/ hk_en/		
India	3030 8282 / 1800 110011 / 1800 3000 8282 / 1800 266 8282	www.samsung.com		
Indonesia	0800-112-8888 / 021-5699- 7777	www.samsung.com		
Japan	0120-327-527	www.samsung.com		
Malaysia	1800-88-9999	www.samsung.com		
Philippines	1-800-10-SAMSUNG(726-7864) / 1-800-3-SAMSUNG(726-7864) / 1-800-8-SAMSUNG(726-7864) / 02-5805777	www.samsung.com		
Singapore	1800-SAMSUNG (726-7864)	www.samsung.com		
Thailand	1800-29-3232 / 02-689-3232	www.samsung.com		
Taiwan	0800-329-999	www.samsung.com		
Vietnam	1 800 588 889	www.samsung.com		
 Middle East 		Ü		
Bahrain	8000-4726	www.samsung.com		
Egypt	08000-726786	www.samsung.com		
Jordan	800-22273	www.samsung.com		
Morocco	080 100 2255	www.samsung.com		
Oman	800-SAMSUNG (726-7864)	www.samsung.com		
Saudi Arabia	9200-21230	www.samsung.com		
Turkey	444 77 11	www.samsung.com		
U.A.E	800-SAMSUNG (726-7864)	www.samsung.com		
■ Africa				
Nigeria	0800-SAMSUNG (726-7864)	www.samsung.com		
South Africa	0860-SAMSUNG (726-7864)	www.samsung.com		

